
# direct drive unit type I

## Jefa 150 KgM autopilot direct drive unit type I


The Jefa direct drive type I is an extremely strong and compact autopilot drive and much more efficient than existing hydraulic and electro-mechanical autopilot drive units (for the why and how, please see our **Q&A** page). It's much stronger than a human being (the max. output torque of 150 KgM is equivalent to 150 Kg force on the end of a 1 meter steering tiller) and is build for 24 hours per day continuous operation with a total weight of only 12 Kgs. The combination of the flat wound (pancake) electric motor with the ultra efficient planetary and spur gearbox results in an extremely efficient drive unit to keep the battery charging time to the minimum. The drive can be used on boats from 30 to 45 foot l.o.a. (or up to 150 Kgm rudder torque) equipped with a mechanical steering system that can be back driven. The direct drive drives the rudder via a draglink and the existing tiller arm or quadrant or via an independent tiller arm. (see illustration)

Please click on the picture for a larger view.






Main dimensions:




The Jefa 150 KgM direct drive type I is very compact with a length of 345 mm, a width of 164 mm and a height of 185 mm. As space is always a problem on sailing yachts, the direct drive unit can be mounted as close as 250 mm from the rudderstock even upside down.

Some mounting possibilities:



The left illustration shows the direct drive combined on the steering tiller lever. The 165 mm output centres are used to achieve the correct geometry. The right illustration shows a direct drive mounted on a separate lever independently from the steering system.

## The two possible operation centres:




Page 4 sur 9



Direct drive type I operating centres in mm valid for 72° (2x36°) rudder travel.				
Output centre distance	Offset distance	Tiller centre distance		
130	106	200		
165 (standard)	127	250		

#### The construction:



The above assembly drawing shows a cross section of the direct drive type I. The drive can be separated in 5 main parts: The electric motor, the two step spur gearbox, the planetary gearbox, the electro-magnetic clutch and the final spur reduction gearbox. The Jefa direct drive has multiple advantages over existing integrated drive units. These advantages will be explained per section of the drive:

**Electric Motor:** The flat wound electric motor (pancake motor) used in the Jefa drive units is carefully selected for this application. Pancake motors have multiple advantages over normal electric DC motors:


- A large flat wound rotor to achieve a high starting toque and an immediate response to the autopilot speed control signal.
- A motor efficiency of 72,5% to achieve a minimal power consumption and maximal mechanical power output (compared to max. 50% efficiency of a normal DC motor).
- Compact main dimensions compared to achievable output.
- Aluminium motor housing in stead of sheet steel plate to avoid corrosion.

**Planetary gearbox:** To achieve a correct rudder travel speed (hard over time) the electric motor has to be reduced in speed with a factor 750:1. Some autopilot drive producers use a worm reduction box, but the efficiency is extremely low as the gears rub each other. The Jefa direct drive type I uses a combination of a planetary gearbox and spur gear sets (one small gear and one big gear). The planetary gearbox has following advantages:


- The highest possible efficiency compared to any other gearbox.
- All forces are equally spread over 3 gear teeth in stead of one allowing a much compacter and stronger solution.
- The forces and torques from the motor to the output shaft remain in the centre line of the drive unit, resulting in a higher efficiency and extremely reduces the loads on the housing and other internal parts.

**Electro magnetic clutch:** On the moment the mechanical steering system on the yacht is manually operated, the autopilot drive has to be disconnected from the steering system. This is achieved with the electromagnetic clutch and controlled automatically by the autopilot junction box. Jefa has developed a unique and patented engagement clutch. The solution is based on two electrically operated spring loaded clutch pins that engage and disengage the outer gear ring of the planetary gear step. This solution has multiple advantages over the existing friction plate clutches:

- Less friction to back drive the unit.
- Lower power consumption (1.4 Amp. at 12 Volt). When the clutch isn't powered, it's disengaged and engaged when powered.
- The clutch doesn't wear in time.
- More compact than any friction clutch.
- When the autopilot is switched off, the helmsman isn't suddenly confronted with the full rudder torque, but has to put loading on the wheel to equalise the forces so the the clutch can disengage, making the manual take over much safer.




## The performance:



This performance table shows the relation between the consumed power and the output power. The red line shows the output torque against the needed amperage at midships rudder and the blue line shows the output torque against the needed amperage at full rudder. The green line shows the hard over time (time to travel 72° of rudder travel) of the drive relative to the output torque. Also visible is the strength of the drive unit related to man power. The unit is much stronger than a human being and can last much longer but one should note that when the unit is operated in the red zone, something is wrong with the trim of the boats and the sails should be adjusted to achieve lower rudder torques. The above table shows that the Jefa direct drive type I will steer the yacht even in the worst possible conditions. As the drive will mostly operate in the left green zone and will not continuously rotate, the average power consumption on 12 volts is 2 amps.


#### Connections:



This illustration shows the minimal components for a working autopilot configuration. Jefa autopilot drives work together with all mayor autopilot electronics. The connection of the Jefa autopilot drive to the autopilot junction box is quite simple. The two 1.5 mm² red and black wires have to be connected to the plus and minus of the autopilot clutch line. This will make sure that when the autopilot user engages the autopilot on the control screen, the clutch will engage and allow the autopilot motor to drive the rudder. The two 2 mm² red and black wires have to be connected to the autopilot drive output connection. Now the Jefa autopilot drive is integrated into the system.

#### Rudder feedback bracket:

To ease the installation of the Jefa autopilot direct drive DD1 we have developed a rudder feedback bracket. This bracket can be mounted in any direction on the main outgoing housing of the drive to accommodate the rudder feedback unit. This saves a considerable amount of installation time as no fundament has to be made for this feedback unit. Please click on the pictures and layout for a larger view.








## Drive unit specification form:



To simplify the specification of the direct drive, we developed a specification form. Please click on the picture to open this form.

## Tiller specification form



<u>Please click this</u> to open the tiller lever specification form in Adobe PDF. This is a great help to specify a tiller arm. Please sent the form to us.

#### Compatibility in 12 Volts.

Following table shows the maximum rudder torques at midships and full rudder that can be generated by the Jefa 150 Kgm direct drive in combination with various autopilot junction boxes.

Autopilot junction box 12 Volt version.	Max. output (Amp.)	Rudder torque midships (KgM)	Rudder torque full rudder (KgM)
Garmin GHP12 sailboat APS (*1)	40	80	150
Simrad AC12	12	80	150
Simrad AC42	30	80	150
Raymarine ACU-200 (*2)	15	80	150
Raymarine ACU-400 (*2)	30	80	150
NKE gyropilot 2 RVP (*3)	25	80	150
Furuno Navpilot	not advisable due to lack in speed control and dynamic braking see this page		
B&G H5000 Pilot (*4)	30	80	150
B&G Tritan Pilot - Low Current	same as Simrad AC12 - see above		

- (\*1) A special Garmin version of the direct drive is available under code number DU-DD1-12/GA. The Garmin rudder feedback unit is integrated and special Garmin cables and plugs are wired to the drive unit.
- (\*2) An internal rudder feedback unit is available for this pilot which saves installation time and a separate fundament for the external rudder feedback is not required. See below pricelist for the surcharge.
- (\*3) Please read the special installation instructions for the clutch available on our FTP server via this direct link.
- (\*4) From software release 1.1.84 onwards. Older H5000 pilots should be software upgraded. For a

## Pricing

Jefa direct drive unit type 1			
Part No.	Description	Price in Euro	
DU-DD1-12	Direct drive 150 KgM type 1 12 Volts	€ 2.009	
DU-DD1- 12/GA	Direct drive 150 KgM, incl. Garmin rudder feedback and cables	€ 2.236	
DU-DD1- RFB1	DD1 integrated rudder feedback unit for Garmin and NKE autopilots (10 $k\Omega$ )	€ 176	
DU-DD1- RFB2	DD1 integrated rudder feedback unit for Raymarine autopilots (5 $k\Omega$ )	€ 176	
DU-DD1-FB	Rudder feedback mounting bracket for DD1	€ 80	

The direct drive should be completed with a  $\underline{\text{draglink}}$ , a tiller pin and in some cases a  $\underline{\text{tillerarm}}$ .